

30" x 20" Logan Single kitchen sinks Reversible Farmhouse FUSF302010

Features

- 29⁵1/₆₄" (757) x 19⁴5/₆₄" (500) x 9²9/₃₂" (252) kitchen sink.
- Single compartment.
- Sink is glazed on all four exterior sides. Suitable for undermount, flush mount, built-up, or above counter installation.
- Farmhouse style with a wrap around 929/32" (252) high apron front.
- Front panel is reversible. Fluted pattern on one side, plain front (no pattern) on other side.
- Made of highest grade fireclay, which is clay heated to an extremely high 1600° making the sink hard and durable, with a beautiful high shine.
- Durability of fireclay means it is resistant to scratches and chips and is easy to clean.
- Extra deep bowl means more room for big pots.
- Fits 36" (914) minimum base cabinet width.

Components

Product includes: Installation Instructions


Options

TSGF30201 Stainless Steel Bottom Sink Grid 2210R Covered Sink Strainer 4010 Covered Disposer Strainer

Warranty

Lifetime Limited Warranty





Specified Model

Model	FUSF302010
Overall	L29 ⁵¹ ⁄ ₆₄ " x W19 ⁴⁵ ⁄ ₆₄ " x D9 ²⁹ ⁄ ₃₂ "
Dimensions	757 x 500 x 252
Bowl Dimensions	L27" x W17 ⁷ / ₈ " x D9 ¹ / ₂ "
	686 x 454 x 241
Drain hole:	35⁄8" (92mm)
Shipping Weight	100.3 lbs. 45.5 kg.
Material	Fireclay
Color	White
Installation	under counter mounted
Required	template, included

Codes/Standards ASME A112.19.3/CSA B45.4


Notes

Install this product according to the installation instructions.




Optional Accessories

TSGF30201 Bottom Sink Grid



2210R Covered Flip Top Sink Strainer.



Water drains easily when cover is in place. Cover flips up with easy touch. Cover makes a flat surface at the sink bottom that prevents food waste from getting into the strainer basket for easy sink clean up. Polypropylene housing. Fits standard 3½" opening.

(Cover is in place

2310 Remote Covered Flip Top Sink Strainer.

4¹⁰/16"

1³⁄₄"

4³/4³

11/3

close drain. Water drains easily when cover is in place. Cover flips up with easy touch. Cover makes a flat surface at the sink


Turn the remote knob to open and

bottom that prevents food waste from getting into the strainer basket for easy sink clean up.

4¾" Polypropylene housing. Fits standard 3½" opening. 1¾" hole required in countertop for remote installation. Remote cable 25½" L.

4010 Covered Flip Top Disposer Strainer.

2¼"



Water drains easily when cover is in place. Cover flips up with easy touch. Polypropylene housing. Top mount installation for 31/2" opening.